



CONGRATULATIONS!

You have just purchased the

FINEST DECK INSERT AND UMBRELLA SLEEVE MADE FOR POOL AND PATIO USE.

COOL POOL DECK INSERT



COOL POOL
6" DECK INSERT
Item Poly-6

- Specification - 2" OD, 1.5" ID, 6" Tall.
- 2 Parts – 6" Polymer Base, Flush Mount Stainless Steel Cap.
- The Cool Pool Polymer Deck Insert has been precision made from Natural Acetal.
- Designed to receive any Volleyball Support or Umbrella with a 1.5" ID.
- The Poly-6 Insert is designed to be installed into your patio decking or directly into your pool.
- Includes custom-made Stainless-Steel caps that will seat flush with your decking.
- Bonding the Poly-6 is not required.

COOL POOL UMBRELLA SLEEVE US Patent # 11,199,018 B2



COOL POOL
8" UMBRELLA
SLEEVE
Item POLY-8 US

- Specifications – 2" OD, 1.5" ID 8" Tall.
- 3 parts – 6" Polymer Base, 2" Stainless Steel Umbrella Adapter, Flush Mount Stainless Steel Cap.
- Cool Pool's patented Umbrella Sleeves are made from Natural Acetal and 303 Grade Stainless Steel.
- Designed to receive any Umbrella with a 1.5" OD pole.
- Bonding the Poly-8 US is not required.
- Screw the Umbrella Adapter into the 6" base and tighten your Umbrella using the thumb screw.
- Remove the Umbrella Adapter from the deck when the Umbrella is removed and add the Stainless-Steel Cap.



INSTALLATION INSTRUCTIONS – NEW CONSTRUCTION

1. Remove Stainless Steel cap and replace with the supplied PVC cap.
2. Locate the best position to install your deck insert or umbrella sleeve.
3. Position the sleeve into the concrete / plaster insuring that it is level and plumb.
4. Set the insert into the wet concrete or plaster so the top rim will remain flush with the decking.
5. Leave the plastic caps in place until the concrete has been set and the acid wash has been completed.
6. Allow decking to set and dry.
7. When completed, Remove the plastic cap and replace with the custom Stainless-Steel cap.
8. Be sure to clean any debris from the threads and inside the insert.
9. DO NOT OVER TIGHTEN THE STAINLESS-STEEL CAP. Using a coin or fingers is all that is necessary.

INSTALLATION INSTRUCTIONS – EXISTING POOL / RETROFIT

1. Remove Stainless Steel cap and replace with the supplied PVC cap.
2. Locate the best position to install your deck insert or umbrella sleeve.
3. “Core Drill” a 2-1/2 – 3” hole at least 6” deep.
4. Set the Polymer Base with your setting compounds of choice.
(Concrete, Plaster, Quick Crete Anchoring, Cement, Etc.)
5. Set the insert so the top rim will remain flush with the decking.
6. Allow your work to set up and dry.
7. Leave the plastic cap in place until the concrete has been set and the acid wash has been completed.
8. Remove the plastic cap and replace with the Stainless-Steel cap.
9. DO NOT OVER TIGHTEN THE STAINLESS-STEEL CAP. Using a coin or fingers is all that is necessary.

IMPORTANT MAINTENANCE TIPS

1. Proper care is recommended with saline or saltwater pools. You should frequently rinse your Stainless Steel with fresh water to avoid salt staining.
2. Do not over tighten the Stainless-Steel caps.

