



CONGRATULATIONS!

You have just purchased the **FINEST STAINLESS STEEL
DECK INSERT AND UMBRELLA SLEEVE**
MADE FOR POOL AND PATIO USE.



COOL POOL
DECK INSERT
Item SSDI

COOL POOL DECK INSERT

- Specification - 2" OD, 1.5" ID, 6" Tall.
- 2 Parts – 6" Base, Flush Mount Cap.
- The Cool Pool Stainless Steel Deck Insert has been precision made from 303 Grade Stainless Steel.
- Designed to receive any Volleyball Support or Umbrella with a 1.5" ID.
- The SSDI Insert is designed to be installed into your patio decking or directly into your pool.
- Includes custom-made Stainless Steel caps that will seat flush with your decking.
- Includes a Stainless Steel grounding screw enabling this part to be bonded to your pool.



COOL POOL
DECK INSERT
Item SS-US

COOL POOL UMBRELLA SLEEVE US Patent # 11,199,018 B2

- Specifications – 2" OD, 1.5" ID 8" Tall.
- 3 parts – 6" Base, 2" Umbrella Adapter, Flush Mount Cap.
- Cool Pool's Patented Stainless Steel Umbrella Sleeve is made from 303 Grade Stainless Steel.
- Designed to receive any Umbrella with a 1.5" OD pole.
- Includes grounding screw enabling this part to be bonded to your pool.
- Screw the Umbrella Adapter into the 6" base and tighten your Umbrella using the thumb screw.
- Remove the Umbrella Adapter from the deck when the Umbrella is removed.



INSTALLATION INSTRUCTIONS – NEW CONSTRUCTION

1. Remove Stainless Steel cap and replace with the supplied PVC cap.
2. Locate the best position to install your deck insert or umbrella sleeve.
3. (Per code) Secure the bonding wire to the outer surface of the insert using the supplied grounding screw.
4. Position the sleeve into the concrete / plaster insuring that it is level and plumb.
5. Set the insert into the wet concrete or plaster so the top rim will remain flush with the decking.
6. Leave the plastic caps in place until the concrete has been set and the acid wash has been completed.
7. Allow decking to set and dry.
8. When completed, Remove the plastic cap and replace with the custom Stainless Steel cap.
9. Be sure to clean any debris from the threads and inside the insert.
10. DO NOT OVER TIGHTEN THE STAINLESS STEEL CAP. Using a coin or fingers is all that is necessary.

INSTALLATION INSTRUCTIONS – EXISTING POOL / RETROFIT

1. Remove Stainless Steel cap and replace with the supplied PVC cap.
2. Locate the best position to install your deck insert or umbrella sleeve.
3. (Per code) Secure the bonding wire to the outer surface of the insert using the supplied grounding screw.
4. “Core Drill” a 2-1/2 – 3” hole at least 6” deep.
5. Set the insert with your setting compounds of choice. (Concrete, Plaster, Quick Crete Anchoring Cement, Etc.)
6. Set the insert so the top rim will remain flush with the decking.
7. Allow your work to set up and dry.
8. Leave the plastic cap in place until the concrete has been set and the acid wash has been completed.
9. Remove the plastic cap and replace with the Stainless Steel cap.
10. DO NOT OVER TIGHTEN THE STAINLESS STEEL CAP. Using a coin or fingers is all that is necessary.

IMPORTANT MAINTENANCE TIPS

1. Proper care is recommended with saline or saltwater pools. You should frequently rinse your Stainless Steel with fresh water to avoid salt staining.
2. Do not over tighten the Stainless Steel caps.

